



Installation Instructions

das Curb Markers®

Using das Curb Marker Adhesive #RS-2225

1. Make sure the surface is clean, dry and flat.
 - If the application surface is painted, all loose paint should be removed. An installation should then be made and tested for adhesion before proceeding further.
 - Read cautionary Statement and First Aid Procedures.
 - Optimum application temperature is 40° F minimum to 90° F maximum.
 - It will skin over in an hour, be firm within 2 hours, and achieve a full cure within 18 hours. (Cure times may vary due to weather conditions.)
2. Apply the das adhesive following the Adhesive Guide® on the back of the marker.
3. **STICK IT!** to the top or to the face of the curb.
 - Push down on the marker hard with a twisting motion forcing adhesive out from the edge.
 - Make sure the entire diameter of the marker has approximately 1/8" of adhesive all around the edge to seal it to the surface.
4. When the adhesive cures the marker is permanently bonded to the surface

